



Steep Channel
Figure 1





Continuous Flow Channel
Figure 1b

High Scour Line - - - -
Low Flow Line - - - -

Channel/Downchute/Spillway
Plan View



Integrated Panel Interlock System
Figure 2



Leading Edge Anchoring
Figure 3

Drawing Not To Scale

ShoreMax™

STEEP CHANNEL/ CHUTE/SPILLWAY DETAIL

* ShoreMax mats can be installed over a variety of underlayments including: sod, turf reinforcement mats (TRMs), geotextiles, and in some cases erosion control blankets (ECBs).

1. Prepare soil before installing erosion control products, including any necessary application of lime, fertilizer, and seed (when installing TRM or ECB underlayment).
2. Install turf reinforcement mat (TRM) over prepared soils according to manufacturer's recommendations.
3. Place ShoreMax mat in the bottom of the channel over the installed TRM (figure 1). The ShoreMax mat should be installed up to the appropriate elevation on the side slope as determined by the engineer. When using multiple panels, connect the panels using the Integrated Panel Interlock System (figure 2). ShoreMax mat can be laid in either direction.
4. For channels carrying continuous water flows, an appropriate geotextile should be placed under the ShoreMax mat for submerged applications (figure 1b).
5. Place staples/anchors in the appropriate pattern. Perimeter staples can be shared between two adjacent panels. In soft or highly erodible soils, percussion earth anchors may be required. View ShoreMax Anchoring Guide, for additional details.
6. At beginning of channel and areas where significant concentrated flows are directed onto the ShoreMax mat, place 1 staple/pin per linear foot along the leading edge of the ShoreMax system, resulting in 1 staple/pin on each corner and gridline (figure 3).

Tensar

NORTH AMERICAN GREEN®

5401 St. Wendel - Cynthiana Rd.
Poseyville, IN 47633

PH: 800-722-2040
www.nagreen.com

Disclaimer:

The information presented herein is general design information only. For specific applications, consult an independent professional for further design guidance.

Drawn on: 3-15-11